




Diametro <i>Diameter</i>	Vetro <i>Glass</i>	Trap <i>Trap</i>	Codice <i>Code</i>	Descrizione <i>Description</i>
12			FR000413	SUPPORTO FRESA PORTA MOLA 12 L 79 DIS.5009
20			FR000426	FRESA 20 H 25 K46 6S D301 DIS.5011
25	4	6/2	FR000505	FRESA 20 H 25 K46 6S+TRAP 25 6/ 2 (4mm) D107
25	5	7/3	FR000506	FRESA 20 H 25 K46 6S+TRAP 25 7/ 3 (5mm) D107
25	6	8/4	FR000411	FRESA 20 H 25 K46 6S+TRAP 25 8/ 4 (6mm) D107
25	8	9/5	FR000412	FRESA 20 H 25 K46 6S+TRAP 25 9/ 5 (8mm) D107
25	10	11/7	FR000414	FRESA 20 H 25 K46 6S+TRAP 25 11/ 7 (10mm) D107
25	12	13/9	FR000507	FRESA 20 H 25 K46 6S+TRAP 25 13/ 9 (12mm) D107
25	15	16/12	FR000508	FRESA 20 H 25 K46 6S+TRAP 25 16/12 (15mm) D107
25	19	20/16	FR000509	FRESA 20 H 25 K46 6S+TRAP 25 20/16 (19mm) D107
50	4	6/2	FR000574	FRESA 20 H 25 K46 6S+TRAP 50 7/ 2 (4mm) D126
50	5	7/3	FR000575	FRESA 20 H 25 K46 6S+TRAP 50 8/ 3 (5mm) D126
50	6	8/4	FR000576	FRESA 20 H 25 K46 6S+TRAP 50 9/ 4 (6mm) D126
50	8	9/5	FR000577	FRESA 20 H 25 K46 6S+TRAP 50 10/ 5 (8mm) D126
50	10	11/7	FR000578	FRESA 20 H 25 K46 6S+TRAP 50 12/ 7 (10mm) D126
50	12	13/9	FR000579	FRESA 20 H 25 K46 6S+TRAP 50 14/ 9 (12mm) D126
50	15	16/12	FR000580	FRESA 20 H 25 K46 6S+TRAP 50 17/12 (15mm) D126
50	19	20/16	FR000581	FRESA 20 H 25 K46 6S+TRAP 50 21/17 (19mm) D126



Diametro <i>Diameter</i>	Vetro <i>Glass</i>	Trap <i>Trap</i>	Codice <i>Code</i>	Descrizione <i>Description</i>
16	4	6/2	FR000467	FRESA 16 H 40 K46 4S D301+TRAP 25 6/ 2 (4mm) D126
16	5	7/3	FR000510	FRESA 16 H 40 K46 4S D301+TRAP 25 7/ 3 (5mm) D126
16	6	8/4	FR000059	FRESA 16 H 40 K46 4S D301+TRAP 25 8/ 4 (6mm) D126
16	8	9/5	FR000334	FRESA 16 H 40 K46 4S D301+TRAP 25 9/ 5 (8mm) D126
16	10	11/7	FR000333	FRESA 16 H 40 K46 4S D301+TRAP 25 11/ 7 (10mm) D126
16	12	13/9	FR000511	FRESA 16 H 40 K46 4S D301+TRAP 25 13/ 9 (12mm) D126
16	15	16/12	FR000512	FRESA 16 H 40 K46 4S D301+TRAP 25 16/12 (15mm) D126
16	19	20/16	FR000513	FRESA 16 H 40 K46 4S D301+TRAP 25 20/16 (19mm) D126



Diametro <i>Diameter</i>	Vetro <i>Glass</i>	Trap <i>Trap</i>	Codice <i>Code</i>	Descrizione <i>Description</i>
16	4	6/2	FR000501	FRESA 16 H 20 K46+TRAP 14+A 6/ 2 (4mm) D126 DIS.527
16	5	7/3	FR000502	FRESA 16 H 20 K46+TRAP 14+A 7/ 3 (5mm) D126 DIS.527
16	6	8/4	FR000175	FRESA 16 H 20 K46+TRAP 14+A 8/ 4 (6mm) D126 DIS 527
16	8	9/5	FR000173	FRESA 16 H 20 K46+TRAP 14+A 9/ 5 (8mm) D126 DIS.527
16	10	11/7	FR000174	FRESA 16 H 20 K46+TRAP 14+A 11/ 7 (10mm) D126 DIS.527
16	12	13/9	FR000327	FRESA 16 H 20 K46+TRAP 14+A 13/ 9 (12mm) D126 DIS 527
16	15	16/12	FR000503	FRESA 16 H 20 K46+TRAP 14+A 16/12 (15mm) D126 DIS.527
16	19	20/16	FR000504	FRESA 16 H 20 K46+TRAP 14+A 20/16 (19mm) D126 DIS.527



Diametro <i>Diameter</i>	Vetro <i>Glass</i>	Trap <i>Trap</i>	Codice <i>Code</i>	Descrizione <i>Description</i>
16	3	5,5/1,5	FR001284	FRESA 16 H 20 K46+TRAP 14+A 5,5/ 1,5 (3mm) D126
16	4	6/2	FR001283	FRESA 16 H 20 K46+TRAP 14+A 6/ 2 (4mm) D126
16	5	7/3	FR001284	FRESA 16 H 20 K46+TRAP 14+A 7/ 3 (5mm) D126
16	6	8/4	FR001285	FRESA 16 H 20 K46+TRAP 14+A 8/ 4 (6mm) D126
16	8	9/5	FR001286	FRESA 16 H 20 K46+TRAP 14+A 9/ 5 (8mm) D126
16	10	11/7	FR001287	FRESA 16 H 20 K46+TRAP 14+A 11/ 7 (10mm) D126
16	12	13/9	FR001288	FRESA 16 H 20 K46+TRAP 14+A 13/ 9 (12mm) D126